

1. Finish CAD document (drawing/model). Your 'drawing' must be finished in order to understand the tools and methods that you will need.
2. Contact print technician to have the work processed. The file now needs to be prepared/programmed into a file that the machine will be able to read.
This also (1) checks for errors in your CAD file and (2) gives you a time estimate for the manufacture of your design.
3. Get on the calendar. You must have a CAM file and a time estimate. No file—no bueno.